

Hose Repair Kit

Our external repair kit for lay flat delivery hoses is designed to work alongside our hose vulcaniser to provide you with the ability to quickly and effectively a repair damage areas of up to 5 mm hole diameter or 10 mm tear length.

CONTENTS: 2 pc. patch repair material, (10 x 15 cm, red - white)
Pair of scissors
Brush
Plastic bottle to be filled with acetone (not supplied)
Teflon folia
Instructions



NOTES:

Good repair results can be achieved for damage up to 5 mm hole diameter or 10 mm tear length. In the case of red coated hoses the "red" side of the patch repair material should be uppermost, and for white (uncoated) hoses the "white" side should be used.

We strongly recommend that large quantities of the patch repair material be stored in a deep freeze (-10° C to 15° C) in order to prolong its usable service life. However the repair material can be purchased as a stock item in small quantities for immediate use if long term storage is a problem.

SHELF LIFE:

We make every effort to always provide fresh patch repair material and send by the quickest means of transport but on receipt we ask our customers to immediately store the material under the following conditions:

Deep freeze
-10°C to -15°C

Refrigerator
+15°C

Room temperature
+20°C

Long term storage
Minimum 24 months

Normal storage
Minimum 12 months

Immediate Workshop Use
4-6 weeks

INSTRUCTIONS



1. Trim off torn threads around the damage to give clean, neat edges.



2. Cut a suitable size patch from the patch repair material allowing a 2 cm overlap of the damage in all directions.



3. Thoroughly clean the damaged area larger than the patch with acetone to remove all traces of oil & grease, etc.



4. Remove the protective film from both sides of the patch and round off the corners.



5. Form a small rubber plug of the repair material and fill the hole to be repaired completely and apply acetone.



6. Apply a generous quantity of acetone to the surface of the underside of the patch until it becomes soft and tacky.



7. Press the patch firmly down on the damaged area.



8. Place the hose with the repaired area in the centre of the base plate (patch uppermost) of the PRONTO P10 vulcaniser and cover the patched area with the sheet of Teflon Release Material.



9. Press down the clamping lever of the vulcaniser to firmly hold the hose area to be repaired. Set the vulcaniser timer for 15 minutes. The vulcaniser will switch off automatically when the curing process is finished.

FOR RUBBER COATED DELIVERY HOSES



For this type of hose first of all remove the external cover around the damage back to the textile reinforcement.



The size of the repair patch should be 2 mm smaller than the removed external cover.

IMPORTANT NOTE

After the vulcanisation period of 15 minutes has finished please keep the hose under pressure until the heating unit has completely cooled down. After 24 hours the hose can be pressure tested with the working pressure according to the prevailing hose standard.